



Assembly No.:193-16

AIR CLEANER

No.	Parts No.	Qty	Parts Name	Specification
1	96000-06028-08	2	HEX WASHER FACE BOLT	6*28
2	17205-120-000	1	AIR CLEANER ELEMENT	
3	17212-120-000	1	OIL CATCH SEAL	
4	17212-120-00A	1	SEAL OIL CLEANER COVER	
5	17206-120-000	1	AIR CLEANER BASE	
6	17207-120-000	1	AIR CLEANER COVER	
7	17232-120-000	1	OIL CATCH COVER	
8	17234-120-000	1	BREATHER FILTER	
9	17235-120-000	1	OIL CATCH FILTER	
10	17253-120-000	1	AIR CLEANER JOINT	
11	17255-120-000	1	AIR INLET DUCT	
12	17257-120-000	1	DUCT AIR CLEANER CASE	
13	17258-120-000	1	IN DUCT SPRING	
14	17370-120-000	1	BREATHER TUBE PLUG	
15	94510-12000	2	CLIP	12mm
16	14110-120-000	1	INTAKE HOSE CLAMP	
17	17200-120-000	1	AIR CLEANER ASS'Y	
18	93500-05010	2	PAN PHILLIPS BOLT	5*10
19	03903-04012	2	TAPPING SCREW TRUSS HEAD PHILLIPS	4*12
20	03903-05020	7	TAPPING SCREW TRUSS HEAD PHILLIPS	5*20
21	17360-120-000	1	DRAIN TUBE ASSY	
22	94509-09000	1	CLAMP	
23	94400-08012	1	TUBE	8*12*240